

# Feeder

Store medication quickly and securely.

## HEADQUARTER GERMANY

Apostore GmbH  
Uferstrasse 10  
45881 Gelsenkirchen  
Germany

Tel. +49 209 94 117 - 0  
Fax +49 209 94 117 - 17

[info@apostore.com](mailto:info@apostore.com)  
[www.apostore.com/en](http://www.apostore.com/en)

**APOSTORE**

Equipment	Feeder Option for A1000, A1000e and Cube*
Feature	Fully automated or Induction device
Storage time	up to 200 packages/h
Installation / attachment	variable on the long side
Mounting surface	1800x450 mm (LxW)
Construction height	770 mm (H)
Function scope Standard	1D barcodes 2D barcodes (data matrix) OCR character reading (expiration date, lot number)
Power requirements	230 V / 16 A
Properties of the packaging to be stored	
Article property	cubic, firmly closed
min. size	20 x 20 x 40 mm (WxHxL)
max. size	100 x 100 x 180 mm (WxHxL)
min. weight	5 g
max. weight	500 g



With the Feeder, you can store medication in your A1000, A1000e or CUBE\* quickly and securely. Because Feeder has a fully-automated induction, you can simultaneously process your direct-delivery orders while special packages and returns can be inserted in parallel into the secondary induction point.

Each medication is isolated, scanned and identified before being transported to the automatic dispensing system. Totes of mixed SKUS can be emptied directly into the Feeder which identifies each product and distributes them into the machine, greatly reducing the workload for operators. When space is limited, the Feeder can fit directly onto automatic dispensers; this flexibility and scalability makes retrofitting possible at any time.